

## PowerMust 600 LCD



### Features

- ⦿ LCD indicator with trendy blue back light for detailed real time status display
- ⦿ Microprocessor control guarantees high reliability
- ⦿ Equipped with Boost and Buck AVR to stabilize input voltage
- ⦿ Built-in DC start function enables UPS to be started up without AC power supplied
- ⦿ Smart RS-232 Communication Port with Free Download Software from the Internet
- ⦿ User-Replaceable Battery Design
- ⦿ Auto charge even though UPS is off
- ⦿ Auto restart while AC recovery
- ⦿ Provides Modem/Phoneline surge protection
- ⦿ Provides Discharge, Overcharge, Short-Circuit and Overload Protection

### Technical Data

Product Type	Uninterrupted power supply line interactive
Capacity	600 VA / 360W
INPUT	
⦿ Voltage	230VAC
⦿ Voltage Range	81-145VAC / 162-290
Output	
⦿ Voltage	220/230/240 VAC
⦿ Voltage Regulation (Battery Mode)	± 10 %
⦿ Frequency	50 or 60 Hz
⦿ Frequency Regulation (Battery Mode)	± 1 Hz
⦿ Output Wave Form	Modified sine wave
Battery	
⦿ Type and Number	12V/7Ah * 1
Back-up Time 100W (PC+15" CRT)	18 minutes
⦿ Recharge Time	6 hours to 90 % after complete discharg
Transfer Time (typical)	4 to 8 ms
Indicator	
⦿ AC Mode	LCD Information
⦿ Back-up Mode	LCD Information
Fault	LCD Information
Audible Alarm	
⦿ Back-up Mode	1 sound signal every 10 seconds
⦿ Battery Low	1 sound signal every second
⦿ Overload	1 sound signal every half-second
Battery exchange	1 sound every 2 seconds
Fault	Continuous sound signal
Protection	Full Protection against discharge, overcharge and overload
Environment	
⦿ Operating Temperature	0 °C - 40 °C
⦿ Humidity Relative,	Relative, 0% ~ 90% (non condensing)
⦿ Noise Level AC mode:	< 40 dB
Interface	
⦿ Smart RS-232 Port	Windows family, Linux, IBM Aix, Sun Solaris, Compaq True64, UnixWare, FreeBSD, HP-UX, and MAC
⦿ USB Port	No
Dimensions (L x W x H)	330 x 100 x 140 mm
Weight	5.6 KG
Accessory	Software, user guide, cables

All rights reserved. Subject to error and change without notice